

14401 Keil Road NE, Aurora, Oregon, USA 97002
PHONE 503-678-6545 • FAX 503-678-6560 • <a href="www.vansaircraft.com">www.vansaircraft.com</a> • <a href="mailto:info@vansaircraft.com">info@vansaircraft.com</a> • <a href="mailto:info@vansa

## **REVISION DESCRIPTION:** 07-06-15

Page: 32-01 REV 1: Updated overall figure with depiction of new VA-110 Detent Bracket configuration

Page 32-07 REV 1: Updated Figure 5 and Figure 6 with depiction of new F-1266AD configuration

New Step 7

New Step 13 Note will be added to Maintenance Manual at next rev change regarding F-1266AD greasing at annual inspection.

Page: 32-08 REV 2: Updated Figure 1 and Figure 2 with depiction of new F-1266AD configuration

Page: 32-09 REV 2: Updated Figure 2 with depiction of new F-1266AD and VA-110 configuration

### **REVISION DESCRIPTION:** 09-29-14

1) Page: 32-03 MEMO: Step 4 should not be bold.

Fix WD-1213 callout in Figure 3.

Page: 32-04 REV 3: Add drill and tap information to Figure 4 "DRILL #3, TAP 1/4-28

BOTH ENDS".

Add make from material "AT6-058X5/16" to Step 4.

Page: 32-05 REV 1: Remove make from material from Figure 1.

2) Page 32-14 REV 3: Add a note before Step 6 "NOTE: Cable tension will change significantly with changing temperature. The cable tensions given below are for an aircraft inside a 70 OF hanger."

In Figure 2 "GROOVE AROUND BARREL TOWARD AFT..." was "GROOVE AROUND BARREL TOWARD FWD..."

3) Page 32-08 REV 1: Added Step 10.

Page: 32-09 REV1:

In Step 1, changed grommet cut length from 3-3/16 to 3-11/16.

In Step 4, changed:

"Install the wings. During installation, slide the A-1211 Pivot Guides into the WD-1214-L & -R Flaperon Torque Tubes and the A-1207-L & -R Actuation Brackets between the F-1261 Spacers as shown in Figure 4."

#### To:

"Install the wings. During installation, use axle grease to lubricate the A-1211 Pivot Guides and A-1207-L & -R Actuation Brackets. The pivot guides slide into the WD-1214-L & -R Flaperon Torque Tubes and the actuation brackets slide between the F-1261 Spacers as shown in Figure 3."



14401 Keil Road NE, Aurora, Oregon, USA 97002
PHONE 503-678-6545 • FAX 503-678-6560 • www.vansaircraft.com • info@vansaircraft.com
Service Letters and Bulletins: www.vansaircraft.com/public/service.htm


Lubrication of the pivot guides and actuation brackets are added to the RV-12 Maintenance Manual in 12CN 01-01-15-1.


# **REVISION DESCRIPTION:** 08-12-13


**32-2 REV 2**: Step 2 revised to describe FLF-00004 Male Nylon Tee installation (vice F 271-N-04X02) installation.

**32-10 REV 1:** Step 1 updated to describe shimming and clamping the flaperons prior to drilling the torque tubes.

Figure 1 updated to show shims and clamps.










FIGURE 1: TRIMMING THE F-1262 FLAP HANDLE BLOCKS

NOTE: Check for interference between the F-1259E Fuel Line Pump - Valve and the WD-1213 Flap Handle or F-1276 Bottom Skin by slipping a piece of paper freely between them. It is permissible to bow the fuel line pump - valve down slightly if necessary.

Step 2: Secure the Flap Handle/ Pushrod Assembly and F-00050 Wire Routing Bracket to the inboard F-1215-L & -R Seat Ribs using the F-1262 Flap Handle Blocks and the hardware called out in Figure 2.




FIGURE 2: INSTALLING
THE FLAP HANDLE/ PUSHROD ASSEMBLY




FIGURE 3: ATTACHING THE FLAPERON MIXER BELLCRANKS

Step 4: Make two F-1264 Control Stick Pushrods from AT6-058X5/16 according to the dimensions given in Figure 4.









FIGURE 4: F-1264 CONTROL STICK PUSHROD














Step 1: Route the spade end (not the fork end) of the F-1239 Rudder Cables along with the 11 1/2 inch long plastic sleeve on both rudder cables, forward through the SB750-10 snap bushings in the F-1207B, F-1206A, and F-1204D & A Bulkheads (see Page 21-14, Figure 3 and Page 21-19, Figure 3). Leave the plastic sleeves at the location shown in Figure 1, then continue routing the cable ends through the two Ø9/16 holes in the F-1203A Bulkhead and the two upper SB750-10 snap bushings in the F-1202F Bulkhead.

Step 2: Using the hardware shown in Figure 1, secure the plastic sleeve on both F-1239 Rudder Cables to the three Ø.191 holes in the center F-1215 Seat Ribs (be sure the MS21919 cushion clamps are oriented as shown). The plastic sleeves are to extend through the Ø9/16 holes in the F-1203A Bulkhead and forward of the bulkhead by approximately 3/8 of an inch.

11 1/2 INCH PLASTIC SLEEVE ON F-1239 RUDDER CABLE, 2 PLACES





FIGURE 1: SECURING THE RUDDER CABLE PLASTIC SLEEVE


Step 3: Drill a #40 hole approximately 3/16 of an inch from the aft end of the 10 inch long plastic sleeve that is on both F-1239 Rudder Cables as shown in Figure 2.

Step 4: Pull the 10 inch long plastic sleeves over the shaft of the fork ends of the F-1239 Rudder Cables and safety wire them to the fork ends as shown in Figure 2.

Step 5: Use the string that was routed through the tailcone in Section 10 to pull the F-1239 Rudder Cables through the snap bushing in both F-1238 Snap Bushing Brackets and out the F-1211 Bulkhead.

Step 6: Temporarily attach one F-1258 Rudder Cable Link to the fork end of both F-1239 Rudder Cables as shown in Figure 3.







**TEMPORARY** 

NUT

F-1239

TEMPORARY


**AN3 BOLT** 

WD-1206


2 PLACES


Pedal Rigging Stop as shown

in Figure 5.



VAN'S AIRCRAFT, INC.





# VAN'S AIRCRAFT, INC.



NOTE: A cable tension meter is required to accurately set the cable tension.

<u>Step 1:</u> Route the F-1247B Aft Stabilator Cables forward through the holes in the F-1207B and F-1206A Bulkheads; see Fig. 1. The cable from the top stabilator horn passes through the upper hole.

<u>Step 2:</u> Route the F-1247A Forward Stabilator Cables aft through the holes in the F-1204A & D Bulkheads shown in Figure 1. The cable from the right pulley passes through the upper hole.

Step 3: Reach through the access holes in the bottom of the fuselage and connect the F-1247A & B Stabilator Control Cables as shown in Figure 2. A wire tool can be made that is inserted into the holes in the cable ends. This will hold them stationary as the barrel is rotated.

<u>Step 4:</u> Place a small weight on the stabilator to hold it trailing edge down. Remove the slack from the upper cable by tightening the upper (outboard) turnbuckle until the control stick and stabilator just start to lift off the stops at about the same time when the stick is moved aft.

Remove the slack from the other cable by adjusting the lower (inboard) turnbuckle. Check the entire length of the cables to ensure they are free from interference, are properly aligned in the pulleys, and do not touch each other. Pull the stick aft to make sure that the stabilator trailing edge moves up.

# NOTE: The F-1227 Seat Ramp Cover must be installed prior to adjusting the cable tension.

Step 5: Install the F-1227 Seat Ramp Cover (Page 33-02, Figure 4). If the screw holes for the F-1233 Control Column Mount Brackets (Page 21-10, Figure 1) do not align with the cover, a light upward pull on the stick will correct the misalignment until the screws are inserted and tightened.

NOTE: Cable tension will change significantly with changing temperature. The cable tensions given below are for an aircraft inside a 70 °F hanger.

Step 6: Position one of the WD-1212 Control Sticks so that the top end is 10 inches from the lower face of the F-1202T Instrument Panel Left or F-1202U Instrument Panel Right (Page 29-07, Figure 2). Secure the control stick in place using a spring clamp to attach it to a 41" long stick bridged between and clamped to the upper longerons.

Check the cable tension just aft of the F-1207B Baggage Bulkhead using a calibrated cable tension meter making sure the control stick is correctly positioned.

Adjust turnbuckles an equal number of turns each to achieve 35-45 lbs of tension with the groove in the cable ends aligned with a V-notch in each turnbuckle barrel as shown in Figure 3. This tension will prevent the cables from "slapping" against the tailcone bulkheads when the control sticks are moved suddenly and repeatedly forward then aft.

<u>Step 7:</u> Remove the clamp and stick from the control stick and the weight from the stabilator.

Move the control stick between the forward and aft pitch stops. The stabilator should reach its travel stops just before the corresponding control stick stops are reached.

